

PASSIVE INFRARED WALL SWITCH OCCUPANCY SENSOR

PW-100

High sensitivity and dense coverage
for exceptional performance

No neutral wire required

Color-matched lens and low
profile for appealing design



Selectable operation, walk-through,
test and presentation modes for
increased energy savings and
convenience

Defaults to Manual-ON operation for
maximum energy savings.



DESCRIPTION

The PW-100 passive infrared (PIR) wall switch sensor can turn lights OFF and ON based on occupancy. It is characterized by high sensitivity to small and large movements, appealing aesthetics, and a variety of features.

OPERATION

The PW-100 replaces existing wall switches and fits in a single gang junction box. It uses advanced PIR technology to detect occupancy and keep lighting ON when it is needed. Once the space is vacated and the time delay elapses, lights automatically turn OFF. DIP switch settings allow for a variety of control options such as Auto-ON operation, walk-through and test modes.

MANUAL-ON CONTROL

Factory default operation is for Manual-ON, so that users turn lights on only when needed. This control strategy is proven to save more energy than Auto-ON, and is in ASHRAE 90.1-2010. If desired, the PW-100 may be reconfigured to turn lights on automatically.

APPLICATIONS

The PW-100 sensor is well suited for small, enclosed spaces with clear line of sight of the occupant. Common applications include small office, small conference room and lunch/break rooms.

FEATURES

- Detection Signature Processing eliminates false triggers and provides immunity to RFI and EMI
- Zero-crossing for long relay life
- Vandal resistant lens combines precise coverage with durability
- Choice of Manual-ON or Auto-ON operation
- Selectable walk-through mode turns lights off three minutes after the room is initially occupied if no motion is detected after the first 30 seconds
- Test mode allows quick and easy adjustments
- Selectable audible and/or visual alerts for impending shutoff
- In automatic mode, sensor returns automatically to Auto-ON after lights are turned off manually; ideal for presentations
- LED indicates occupancy detection
- Optional light level sensing with simple setup
- Service mode allows sensor to operate as a service switch in the unlikely event of a failure
- Sensor coverage tested to NEMA Guide Publication WD 7-2000
- Compatible with decorator wall plates

PROJECT

LOCATION/
TYPE

- PW-100: 120/277 VAC; 50/60 Hz
 - @ 120 VAC, 0-800 W ballast or tungsten, 1/6 hp
 - @ 277 VAC, 0-1200 W ballast
- Time delays: 5, 10, 15, 20, 25 or 30 minutes, walk-through, test-mode
- Sensitivity adjustment: PIR (high/low)

- Coverage: Major motion 35' x 30'
Minor motion 20' x 15'
- Dimensions: 2.73" x 1.76" x 1.83" (69.3mm x 44.7mm x 46.5mm) L x W x D
- UL and cUL listed
- Five year warranty

ON/OFF Button

DIP Switches

Detection LED

PIR Lens

The diagram shows the rear of the PIR sensor unit. At the top, there is a rectangular ON/OFF button. Below it, a row of three DIP switches is visible. Further down, a small LED is labeled as the Detection LED. The bottom section features a large, vertically-oriented PIR lens. A separate inset shows the front of the unit, which has a single oval-shaped lens.

The diagram shows the physical layout of the control panel with the following labels and switch positions:

- Time Delay:** Switches 1, 2, and 3.
- Walk-Through:** Switch 4.
- PIR Sensitivity:** Switch 5.
- Visible Alert:** Switch 6.
- Audible Alert:** Switch 7.
- ON Mode:** Switch 8.
- Not Used:** Switch 9.

Arrows indicate the direction of the switches: down for 'Test', '5 minutes', '10 minutes', '15 minutes', '25 minutes', '30 minutes', 'Disabled' (Walk-Through, Visible Alert, Audible Alert), and 'Auto On'. Up for 'Service', 'Enabled' (Walk-Through, Audible Alert), 'Low, 50%', and 'Manual On'. A factory setting arrow points to switch 4.

This diagram illustrates a 3-phase 4-wire system. It features three phase wires labeled 'Line' (Black, Green/Yellow, and Ground Green) and one neutral wire labeled 'Neutral'. The neutral wire is connected to a 'Load' box. The system is grounded at the bottom, indicated by a ground symbol.

Catalog #		Color	Voltage	Load Rating
	PW-100-W	White	120/277 VAC; 50/60 Hz 2-wire sensor; no neutral connection	@ 120 VAC, 0-800 W ballast or tungsten, 1/6 hp
	PW-100-LA	Light Almond		@ 277 VAC, 0-1200 W ballast
	PW-100-I	Ivory		
	PW-100-G	Gray		
	PW-100-B	Black		

27364r2 Rev 07/2021