



| | |
|---------------------------------|---|
| [Numeric Key] + [CAM] | Call Camera |
| [Numeric Key] + [PRESET] | Call Preset |
| [LENS] | Change Lens Zoom Speed [Telemetry Receiver] WIPER: Control housing wiper switch |
| [ICR] | Change IR CUT Status [Telemetry Receiver] SPRAY: Control housing spray switch |
| [MENU] (SET) | Call Menu [Telemetry Receiver] AUX1: Switch 1 |
| [ESC] | Exit Menu [Telemetry Receiver] LIGHT: Control assisted illuminant Switch |
| [AUTO PAN] | Call Auto Pan |
| [ZOOM IN] | Lens Zoom In |
| [ZOOM OUT] | Lens Zoom Out |
| [LEFT] | Move Left |
| [RIGHT] | Move Right |
| [UP] | Move Up |
| [DOWN] | Move Down |
| [FLIP] | Rotate 180° [Telemetry Receiver] AUX2: Switch 2 |
| [FOCUS FAR] | Focus Far |
| [FOCUS NEAR] | Focus Near |
| [AUTO FOCUS] | Auto Focus |
| [IRIS OPEN] | Iris Open |
| [IRIS CLOSE] | Iris Close |
| [AUTO IRIS] | Auto Iris |
| [54] + [F4] | Start Memorizing Patrol Learn |
| [55] + [F4] | Stop Memorizing Patrol Learn |
| * [1] + [LOCK] | Close Password |
| * [2] + [LOCK] | Open Password |
| * [3] + [LOCK] | Edit Password |
| * [4 of Numeric Keys] + [ENT] | Enter Password |
| * [9011] + [CLR] | Clear Preset Position |
| * [9013] + [CLR] | Reboot System |
| * [9015] + [CLR] | Reset Camera |
| [51] + [F4] | Setting Return Delay time ON/OFF |
| [52] + [F4] | Setting Return Mode |
| [53] + [F4] | Select Auto Mode |
| [Numeric Keys 1,2,3,4] + [F4] | Group Setting |
| Preset Position Saving | 1. [1~255] + [F1] Setting Preset Position Speed 2. [1~255] + [F2] Setting Preset Position Dwell Time 3. [1] + [F3] Saving Preset Position |
| * Single Preset Position Saving | [SHIFT] + [Numeric Keys] + [PRESET] + [ENT] (Setting DWELL: 5 sec. / SPEED: 255/sec.) |
| * Single Preset Position Delete | [SHIFT] + [Numeric Keys] + [PRESET] + [CLR] |

NOTE : * Only MLP2 to support this function